





Leak Switches

Leak switches come in two configurations. For interstitial space leak detection, the probe will be mounted from the top of the tank. It will be identical to the multi-level probe described above except with only one float at the bottom. These are usually mounted within two inches of the bottom of the tank.

In other configuration a leak switch which is mounted in the base pan area of a pump set or filtration set to detect an oil spill. These are usually directly wired to controllers mounted on the pump set.



Subject to Change without notice

V.1.13014.DS

Our Fuel Oil Pump Set products are only a part of our complete family of equipment that makes up a typical fuel oil system. Please contact us for your complete system needs.

